

Assembling instruction

Warning!

Adult assembly required before giving to child.
Check fittings regularly to ensure they are fully tightened.
Remove all packaging before giving toy to child
Very young children should be supervised at play.
Only for domestic use.

List of components: 5 B screws, 1 A screw, 1 allen key, 2 legs, 1 sit, 1 head, 1 rocker.

Please retain this information for future reference.

